

# SuperSwitch<sup>™</sup> Interface Integral Liquid Level Switch

Model LL-107

## Ultrasonic Sensing Technology

**IDEAL FOR:** 

- Single Point Interface
  - Oil/Water
  - Coal Slurry/Oil
- Multi-Point Interface
- Slurry and Sludge Density

### **ADVANTAGES**

Easy Installation and Set-up 3/4" NPT Mounting No Calibration

**Maintenance Free** 

Rugged Construction Compact Sealed Electronics 316 Stainless Steel Sensor

High Pressure Operation Up to 1000 psi

Agency Approvals FM - Factory Mutual CSA - Canadian Standards Association *HITECH's* Model LL-107 is an integral interface switch capable of detecting the interface of two immiscible liquids. It can also detect the interface of a liquid and settled solids.

The discrimination occurs from the differences in physical properties of the liquids. The ultrasonic signal is attenuated in one liquid as compared to another liquid. A multipoint interface sensor version is also available.

Requiring no calibration, the **Interface Switch** with its compact design and 3/4" NPT mounting is unbelieveably easy to install.

The miniaturized, encapsulated and totally sealed electronics, housed in a cast aluminum, explosionproof, watertight enclosure is designed to provide many years of maintenance-free service.

#### HITECH Technologies, Inc.

301 Oxford Valley Road, Yardley, PA 19067-7706 Technical support: 800. 755. 4507 Tel: 215. 321. 6012 ~ Fax: 215. 321. 6067 ~ www.hitechtech.com




# SuperSwitch<sup>™</sup> Interface **Integral Liquid Level Switch**

Model LL-107

### **SPECIFICATIONS**

#### **Input Power** Type Sensor Ultrasonic Interface Level Switch Standard 115 or 230VAC Standard 316 Stainless Steel 50/60 HZ **Repeatability:** Optional 12 or 24 VDC Mounting 0.08 " or better 3/4" NPT Standard **Outputs** Optional Flange mount Delay (on) Standard 10A DPDT relay Standard 0.5 seconds Temperature Housing Electronics -20 °F to +170 °F NEMA 4 & 7 Pressure Sensor $-40^{\circ}$ F to $+300^{\circ}$ F Cast Aluminum Up to 1000 psig 3-3/4" 4"



APPLICATIONS	SINGLE POINT INTERFACE
MULTI-POINT INTERFACE SLURRY DENSITY SLUDGE DENSITY	SINGLE POINT INTERFACE SLURRY DENSITY SLUDGE DENSITY

### **PERFORMANCE GUARANTEE**

Since 1986, every instrument sold by HITECH has been guaranteed to perform in the application it originally was engineered and recommended for. Our company policy remains the same, every product sold comes with a written performance guarantee.

Should the equipment be unable to perform satisfactorily in your application and we are not able to correct the problem, we will accept the instrument in return and issue full credit.

This performance guarantee is valid for 60 days. Thereafter, our standard limited two years factory warranty goes into effect.

Copyright HiTECH Technologies, Inc.2000

### **HITECH** Technologies, Inc.

301 Oxford Valley Road, Yardley, PA 19067-7706 Technical support: 800. 755. 4507 Tel: 215. 321. 6012 Fax: 215. 321. 6067 www.hitechtech.com